

INSTRUCTION

Turn the chair upside down. Carefully remove the non-woven fabric under the chair.

Turn the chair to upright position. Press down the wings with laces between the seat and the back. Turn the chair upside down again and pull out the laces. Tie them together and put the non-woven fabric back again.

ARTWOOD

— SINCE 1969 —

DIFFERENT WAYS OF LIVING